DEUTSCH COLOR

GRIFF L45



DESCRIPTION

Wallpaper adhesive based on high-quality cellulose

CHARACTERISTICS

- · Does not clump
- Non-stainingEasy to apply
- Easily correctable
- Super-strong
- Ready for use within 15 minutes
- Airtight packaging
- pH-neutral
- Moisture resistant

RECOMMENDATIONS FOR USE

Suitable for applying all types of light, medium and heavy wallpaper, including paper, simplex, duplex and acrylic wallpaper.

APPLICATION METHOD

Brush, roller, airless spray

DILUENT

Water

WATER DEMAND

10 Liters

TECHNICAL DATA Base: Celuloze Density after preparation: 1,05±0,02 gr/ml Form: Powder 15 m² / Lt Opening rate: Workability time: 20±5 min The drying time depends significantly on the substrate absorption capacity and on the Application of product conditions, relative humidity and relative humidity 3 min of the air: pH: $7,5 \pm 1$ Color: White, translucent after drying

DEUTSCH COLOR

APPLICATION

Surfaces must be clean, dry and free from all defective and poorly adhering material, dust, dirt, oils and salts. Add the powder in small quantities to cold water while vigorously stirring until the mixture is homogenized and lump-free. Let the created paste to rest and stir up vigorously again after 10 minutes. It will be then ready to use. Coat the wallpaper strips thoroughly and evenly with a fur roller or brush, making sure the edges are properly covered. Fold the strips in doubles and allow the paste to soak in following the instructions of the wallpaper manufacturer. Apply a strip of paper to the wall and brush it smooth using a plastic spatula or brush. Always smooth the wallpaper from the centre to the edges, and from top to bottom. Make sure that the seams are properly pressed against each other. Tools are cleaned immediately after the application with soap and water.

STORAGE

24 months, stored in a closed box and normal storing conditions.

CONSUMPTION

0.1 Kg/m²

PACKAGING

0.25 Kg plastic boxs

HEALTH AND SAFETY INFORMATION

Keep out of reach of children. In case of contact with the eyes or swallowing, please seek medical advise immediately and show the contents of the container. Do not dispose the product into drains.





